



DIP SWITCH 1-SYSTEM

Game Charge		1 coin 1 play	1 coin 2 plays	1 coin 3 plays	2 coins 1 play
SW 1	RIGHT HAND	OFF	ON	OFF	ON
SW 2	SELECTOR	OFF	OFF	ON	ON
SW 3	LEFT HAND	OFF	ON	OFF	ON
SW 4	SELECTOR	OFF	OFF	ON	ON
Special Purpose					
SW 5	MUST BE LEFT OFF	OFF			
SW 6		OFF			
Cocktail/Upright		CT	UP		
SW 7	CONTROL PANEL	OFF	ON		
SW 8		OFF	ON		

DIP SWITCH 2-GAME FEATURES

Number Of Credited		3	4	5	Unlimited Lives
SW 1		OFF	ON	OFF	ON
SW 2		OFF	OFF	ON	ON
Bonus Points		first 20,000 and every 40,000	30,000 50,000	50,000 70,000	20,000 once only —
SW 3	points required for	OFF	ON	OFF	ON
SW 4	bonus player	OFF	OFF	ON	ON
Difficulty		easy	regular	difficult	very difficult
SW 5		OFF	ON	OFF	ON
SW 6		OFF	OFF	ON	ON
Attraction Mode Sound		NO		YES	
SW 7		OFF		ON	
Hit Check Of Boomer		YES		NO	
SW 8		OFF		ON	