


FRONT LINE DIP SWITCH SETTINGS

		SWITCH A							
SETTING	POSITION	1	2	3	4	5	6	7	8
BONUS POINTS (FOR ADDING ONE SOLDIER)	10,000	OFF	OFF						
	20,000	ON	OFF						
	30,000	OFF	ON						
	50,000	ON	ON						
FREE PLAY	NORMAL FREE PLAY			OFF ON					
NUMBER OF SOLDIERS	3				OFF	OFF			
	4				ON	OFF			
	5				OFF	ON			
	6				ON	ON			
TEST MODE	NORMAL TEST						OFF ON		
SCREEN INVERSION								OFF ON	
GAME STYLE	TABLE UPRIGHT								OFF ON
SWITCH B									
<div style="display: flex; justify-content: space-around;"> ONE WAY TWO WAY </div>									
1 COIN	1 PLAY	ON	ON	ON	ON	ON	ON	ON	ON
1 COIN	2 PLAYS	OFF	ON	ON	ON	OFF	ON	ON	ON
1 COIN	3 PLAYS	ON	OFF	ON	ON	ON	OFF	ON	ON
2 COINS	1 PLAY	ON	ON	ON	OFF	ON	ON	ON	OFF
3 COINS	1 PLAY	OFF	ON	ON	OFF	OFF	ON	ON	OFF
4 COINS	1 PLAY	ON	OFF	ON	OFF	ON	OFF	ON	OFF
SWITCH C									
COINAGE DISPLAY	WITH WITHOUT	X				OFF ON			
YEAR DISPLAY	WITH WITHOUT	X					OFF ON		
NO HIT	NORMAL NO HIT	X						OFF ON	
COIN WAY	2 WAYS 1 WAY	X							OFF ON

OPTION SWITCHES
FIGURE 1



VOLUME CONTROL LOCATIONS
FIGURE 2

